

Element H: Prototype testing and data collection plan

TESTING

All of the tests were authorized by [teacher's name redacted].

[teachers name redacted].... Engineering Teacher

The first visibility test procedure was written to test the amount of light reflected by certain material samples. The intent was to determine the ideal material to use in the Mirror Sections to reflect the light, thereby giving the device its periscope function. This test was labeled as Material Reflectance Test. The test document is as follows:

Testing Date:

Purpose: To determine the *percent* of light reflected by a sample of a material

Pass/Fail Criteria: Pass- a value *for the percent* of light reflected is determined

Fail- a value for the percent of light reflected is not determined

Materials Required:

1. material sample(s)
2. dark room
3. Science Workshop interface
4. Computer with Science Workshop software
5. Pasco SC-100 light sensor
6. laser pointer

Initial Conditions:

1. The area must be dark with no visible light sources other than the testing equipment.
2. Permission to use the equipment has been granted.
3. Science Workshop software has been installed onto the computer.

Safety Concerns:

Hazard	Control	Compliance
1. Light emitted by the laser pointer may be directed at someone's eye, thereby potentially damaging the eye	IA. Only people necessary to the performance of the test will be present in the dark room during the test. IB. The person operating the laser pointer will be aware of the presence and position of all people in the dark room and will make sure that he or she does not aim the laser at anyone. IC. No one will ever be at eye level with the laser pointer.	IA. IB. IC.


Terminations:

1. The emitted laser light damages someone's eye.



Stepwise Procedure:

1. Ensure that all required materials are on hand
 2. Ensure that all initial conditions are met
- COMPLIANCE:
COMPLIANCE :

3. Em;urethatal1S1ft1t1tmtrol.sarein p4ace COMPtJANct.:
 4. Optn11>t Wo<shop10flw>roll'<'S'*m
 5. Stlup1lle1LIGHTSENSOR irtpoJ> onPIOC'*m
 6. Open the ijbr' lion bo<
 7. PO!!!iontlttght<en!Ot!Othatltbeblorlllg ambientllgl1l1rorn llleroom
 8. Selttlisv*!Uoofliel>l »lhemlnloklnm ••h•
 9. Shon• 1htInt' PO!ter ctyal •lel&h1 ;oruor
 10. Set this value offight as 'hemaxlmomvcilu.
 11. Tum <>ll lhel>S« painler
 12. Clo••!!lealolmlonbo•
 13. S.t.tlt P•KO lfc>\ ,<Of D ,,,•monotol" lunalon d...OUlpul IQ the Or<rTAL output
 14. R«ord the material of ttwfirst sample fnthe Rtflecc1ruditi! tilbfe
- IS Setup the __pointer, lle first sample, me hght sensor as !!low while following dagnm
wttl one onhokfingthe Qmple end analhHJk'ISO nolff'atlng the'tar 3Nf twf sensor



$$\theta_1 = \theta_2$$



16. Activa the laser pointer and make •ur• thatany l'<!!lected fill>l isbeing rellee:t10d mtho lght sensor
17. Rec:ord the per<en!OJ• of light det«ted by th• liaht In th• Refl«IMI<« dati r.ablt
18. Tum olf the laseq>oi<'11er
19. Repeat steps 14th 18fOf any oddllion.>l ,mplos

Ai.rthoNed Sfcn.atute:

Data:

Reflectance	
material	light reflected (%)
aluminum foil	
mirror	

Another visibility test had the purpose of determining any alignment errors in the mirrors in the visibility prototype. This test was called the Mirror Angle Test. The details of The Mirror Angle Test are included in the following test document:

Test Item:

rt 51/13

Purpose: To determine the difference in alignment of the light entering one viewport of the device and exiting the other viewport.

Pass/Fail Criteria: Pass-The average alignment difference from 90° is 5° or less.

Fail-The average alignment difference from 90° is greater than 5°.

Materials Required:

1. device prototype with mirror sections attached
2. laser pointer
3. plain white computer paper
4. tape
5. protractor
6. ruler or straight edge
7. protractor sheet (Appendix A attached at the end of the test document)

Initial Condition:

1. Permission to use the equipment has been granted.
2. A suitable testing area is found that is within three feet of a wall.
3. The testing area is set up as specified in the following conditions:
 - a. Setup the device prototype on its side on a table with one viewport facing the wall, as shown in Figure 1.

Figure 1: _____



- b. Tape a sheet of plain white computer paper in front of the device prototype viewport not facing the wall.
- c. Use the protractor and straight edge to draw a line perpendicular to the viewport that is not facing the wall on the sheet of paper in front of it, shown as line A in Figure 2.
- d. Ready the laser pointer so that the light will be detected along line A on figure 2.

Figure 2: _____







- e. Activate the laser pointer at a downward angle. Then, actually angle it upward along the line. Continue to angle it up until the top of laser can be seen just outside of the viewport facing the wall. Hold the laser pointer at this angle.
- f. A second test tape the protractor sheet off the device prototype viewport facing the wall with the horizontal line at the edge of the viewport touching the table or ground and the 'X' at the tip of the laser, as shown in figure 3.

Figure 3:



- g. Deactivate the laser pointer.
- h. Repeat steps (e) and (g) and make sure that the tip of the laser hits the exact point of the 'X'.

Safety Concerns

Hazard	Control	Compliance
Light emitted by the laser pointer may be directed at someone's eye, thereby potentially damaging the eye	<p>1A. Only people necessary to the performance of the test will be present within five feet of the test.</p> <p>1B. The person operating the laser pointer will be aware of the presence and position of all people within five feet of the test area and will make sure that he or she does not aim the laser at anyone.</p> <p>1C. No one will ever be at eye level with the laser pointer.</p> <p>1D. The laser pointer will always be pointed in the direction of the wall.</p>	<p>1A. </p> <p>1B. </p> <p>1C. </p> <p>1D. </p>

Terminations:

1. Any of the contr scenarios described in the Safety Concerns section above are no longer in compliance.

Startup Procedure:

1. Ensure that all required materials are on hand



2. Ensure that all initial conditions are met
3. Ensure that all safety controls are in place
4. Angle the laser pointer upward until a degree measurement off from the 90° mark on the protractor sheet can be discerned.
5. Record this measurement in the Angle Offset Data table.
6. Deactivate the laser pointer.
7. Repeat steps 4 through 6 for a total of five trials.
8. Calculate the average of the data in the Angle Offset Data table.

Author's Signature:

1 (zA_ 10/ Pf >

Data:

Angle Difference	
Trial Number	Angle Measurement from 90°
	2° to the right
	1° to the right
	4° to the left
4	2° to the right
5	4° to the left

